



Manual

LES02D

CAN

Table of Contents

| | |
|---|-----------|
| 1 Document | 3 |
| 2 General Information | 4 |
| 2.1 Target Group..... | 4 |
| 2.2 Symbols used / Classification of the Warnings and Safety instructions | 4 |
| 2.3 Preliminary Remark | 5 |
| 2.4 Transport / Storage | 5 |
| 2.5 Other Applicable Documents | 5 |
| 3 Product Description | 6 |
| 3.1 Functional description | 6 |
| 3.2 Functional Specification | 6 |
| 3.3 Technical Data | 7 |
| 3.3.1 Sensor | 8 |
| 3.4 Sensor Terminal Assignment..... | 9 |
| 4 Commissioning and Operation | 10 |
| 4.1 CAN communication | 10 |
| 4.2 Data Transmission | 10 |
| 4.3 Data telegram design..... | 11 |
| 4.3.1 Data telegrams during the start sequence..... | 11 |
| 4.3.2 Data telegrams during operation | 11 |
| 4.4 Supported commands..... | 11 |
| 4.5 Status LED..... | 11 |
| 4.6 CAN Error Codes | 12 |
| 4.7 Failures | 15 |
| 5 Disposal | 16 |
| 6 Annex | 17 |
| 6.1 Decimal / Hexadecimal conversion table..... | 17 |
| 7 Contact | 19 |
| Glossary | 20 |

1 Document

This is the English translation of the original manual in German language.

| | |
|------------|---|
| Publisher | Kübler Group, Fritz Kübler GmbH Schubertstraße 47 78054 Villingen-Schwenningen Germany www.kuebler.com |
| Issue date | 04/2024 |
| Copyright | © 2024, Kübler Group, Fritz Kübler GmbH |

Text sources

Image sources

Code sources

Legal Notices

All of the contents of this document are protected by the rights of use and copyrights of Fritz Kübler GmbH. Any duplication, modification, further use and publications in other electronic or printed media, as well as their publication in the Internet, even partially, is subject to the previous written authorization by Fritz Kübler GmbH.

The brand names and product brands mentioned in this document are trademarks or registered trademarks of the respective titleholders.

Subject to errors and changes. The stated product features and technical data shall not constitute any guarantee declaration.

2 General Information






Please read this document carefully before working with the product, mounting it or starting it up.

2.1 Target Group

The device may only be planned, mounted, commissioned and serviced by persons having the following qualifications and fulfilling the following conditions:

- Technical training.
- Briefing in the relevant safety guidelines.
- Briefing in the operation by the machine operator.
- Constant access to this documentation.

2.2 Symbols used / Classification of the Warnings and Safety instructions

| | |
|--|---|
|  DANGER | <p>Classification:</p> <p>This symbol, together with the signal word DANGER, warns against immediately imminent threat to life and health of persons.</p> <p>The non-compliance with this safety instruction will lead to death or severe adverse health effects.</p> |
|  WARNING | <p>Classification:</p> <p>This symbol, together with the signal word WARNING, warns against a potential danger to life and health of persons.</p> <p>The non-compliance with this safety instruction may lead to death or severe adverse health effects.</p> |
|  CAUTION | <p>Classification:</p> <p>This symbol, together with the signal word CAUTION, warns against a potential danger for the health of persons.</p> <p>The non-compliance with this safety instruction may lead to slight or minor adverse health effects.</p> |
| ATTENTION | <p>Classification:</p> <p>The non-compliance with the ATTENTION note may lead to material damage.</p> |

| | |
|---------------|--|
| NOTICE | Classification: |
| | Additional information relating to the operation of the product, and hints and recommendations for efficient and trouble-free operation. |

2.3 Preliminary Remark

The following basic safety instructions are intended to avoid personal injuries and damage to property; they relate primarily to the use of the products described herein. If you additionally use further components, also consider their warnings and safety instructions.

2.4 Transport / Storage

Check the delivery immediately upon receipt for possible transport damages. If you do not mount the device immediately, store it preferably in its transport package.

The device must be stored at a dry and dust-free location, in compliance with the technical data, see chapter Technical Data [▶ 7].

2.5 Other Applicable Documents

| | |
|---------------|--|
| NOTICE | Technical Data |
| | All technical data, as well as the mechanical and electrical characteristics, are specified in the data sheets of the corresponding device variant, for special versions in the corresponding quotation / customer drawing of the product. |

All documents such as the original declarations of conformity or the relevant certificates can be downloaded from our homepage:

www.kuebler.com/de/docu-finder

For the evaluation of the safe sensor, observe the respective operation manual of the system to be commissioned. The evaluation unit or control must comply with the requirements of the interface description and with the safety-related technical specifications.

3 Product Description

3.1 Functional description

LES02D

The sensor that is mounted on the elevator car and the coded band that is tensioned in the shaft form together the measuring system. The sensor converts a linear motion into a digital position signal. To this purpose, it evaluates the band, which is coded by two rows of holes.

3.2 Functional Specification

The electrical, electronic and programmable subsystem Safe Sensor LES02D may only be used in elevator facilities in conjunction with a suitable evaluation unit. The safety subsystem LES02D consists of the sensor and the coded band (stainless steel). The sensor LES02D reads the absolute position of the coded stainless steel band, which is mounted suspended in the shaft over the entire travel height. Band errors are recognized. The messages consisting of position, speed and error status are continuously transmitted every 4 ms via two redundant CAN bus communication links. Downstream evaluation unit(s) evaluate and process the messages. Together with this evaluation unit, an Elevator Directive-compliant electrical, electronic and programmable system can be achieved for safety-related applications in elevators.




Fig. 1: Option 1: use with two evaluation units

IMG-ID: 27021598090242059




Fig. 2: Option 2: use with one evaluation unit

IMG-ID: 27021598090240139

What the measuring system does not fulfill

The following is not provided by the measuring system; this must be ensured by external devices:

- The measured position is not evaluated. This requires a safe evaluation unit or controller that will be able to fulfill various position-dependent safety functions.
- The measuring system in no way actively intervenes in the elevator system. It is purely a position sensor.
- The scope of the measuring system is not to measure lengths. Lengths vary in particular because of the temperature and other influencing factors.

3.3 Technical Data

| NOTICE | Technical Data |
|--------|--|
| | All technical data, as well as the mechanical and electrical characteristics, are specified in the data sheets of the corresponding device variant, for special versions in the corresponding quotation / customer drawing of the product. |

3.3.1 Sensor

Mechanical characteristics sensor

| | |
|--|-------------------------------------|
| Operating temperature | -10°C ... +70 °C [14°F ... +158°F] |
| Storage temperature | -15°C ... +80 °C [5°F ... +176°F] |
| Protection level according to EN 60529 | IP54 |
| Maximum air humidity | <90 % (non-condensing) |
| Installation height | <2000 m [<6561 ft] |
| Material Housing | Aluminum |
| Weight | appr. 0,55 kg [1.213 lbs] |
| Maximum measuring length | 392 m [1286 ft] |
| Maximum nominal speed of the elevator | 8 m/s [26.25 ft/s] |
| Maximum speed | 10,5 m/s [34.45 ft/s] |
| Resolution | certified 1 mm functional 0,5 mm |
| Accuracy position | ±1 mm [±0.04"] |
| Speed tolerance | < 5 % |

Electrical characteristics sensor

| | |
|--|----------------|
| Supply voltage | 10 ... 30 V DC |
| Supply voltage according to UL 1310 | Class 2 |
| Supply voltage | SELV / PELV |
| Maximum current consumption | 100 mA |
| Protection class according to EN 61140 | III |

Sensor Connection Technology

| | |
|---------------------|-------------------------------|
| Cable at the sensor | 3 m |
| | 0.25 mm ² per wire |
| | Twisted pair |
| | shielded |

Please note chapter Electrical Installation.

EMC- Electromagnetic compatibility

| | |
|-------------------|--------------------------------|
| Relevant standard | EN 12015:2014 EN 12016:2013 |
|-------------------|--------------------------------|

3.4 Sensor Terminal Assignment

| Interface | Cable, shielded, open cable end | | | | | | |
|-----------|---------------------------------|----|---------|--------|--------|------------|--------|
| CAN | Signal: | +V | 0 V/GND | CAN1_H | CAN1_L | CAN2_ H | CAN2_L |
| | Wire color: | BN | WH | GN | YE | GY | PK |

4 Commissioning and Operation


4.1 CAN communication

The prerequisite for understanding this first part of the chapter is advanced knowledge regarding the design, use, and evaluation of CAN buses as well as of bus protocols.

This section is not required for the proper installation and start-up of a certified evaluation unit. If the complete system is not functioning, the following section will provide possible fault diagnoses and corrective measures. In case of doubt please contact Technical Support [▶ 19].

Using the device with an external evaluation unit requires a definitive exchange protocol as presented in the following. An evaluation unit that wants to use the device must meet all requirements.

The complete system must be replaced if there is mechanical damage of any kind. The only exception is worn slide rails. The latter indicates a plant assembly error.

| | |
|---|---|
|  DANGER | <p>Evaluation unit safety functions</p> <p>If position data is missing, the evaluation unit must guide the elevator system to a safe state using adequate means (and in dependence on the safety function).</p> <p>Whether operation can resume after a fault, i.e., a reset is permitted, is determined by the switch commands stored in the evaluation unit.</p> <p>Please follow the chapter “Functional Safety” in the operating instructions; refer to document R60109.</p> |
|---|---|

The device architecture stipulates that two independent channels (called Channel A and Channel B in the following) send alternating position data. ID number 0x0A is assigned to Channel A and 0x0B is assigned to Channel B. The CAN packets are 8 bytes long.

The meaning, timing, and other constraints are specified as follows. The 8 possible data bytes of a CAN message are numbered from 0 to 7, where 0 is chronologically first. The “0x” prefix indicates hexadecimal numbers [▶ 17]. Data values not specified here are reserved for internal device purposes.

4.2 Data Transmission

| Measure | Description |
|---------------------------------------|--|
| Alternating sending by channels | In normal operation, each channel sends its data every 4 ms. Channel B synchronizes to the half interval of Channel A, so that data packets are sent every 2 ms. |
| Data must be checked for plausibility | The evaluation unit checks the positions for plausibility in order to detect transmission errors unable to be captured by the CAN protocol (depending on the SIL of the complete system). |
| Specified CAN ID Use | The CAN IDs are used in the 11 bit standard. Channel A always receives ID 0x0A, Channel B ID 0x0B. |
| Only LES may send via CAN bus | Only the LES sensor can send messages using the CAN bus. The sending of LES reset commands by the evaluation unit is the only exception. If an invalid message is detected an error is output and the sensor locked. |

4.3 Data telegram design

4.3.1 Data telegrams during the start sequence

After switch-on, in the start sequence both channels send two startup telegrams.

| | |
|---------------|--|
| NOTICE | Identifying startup telegrams |
| | The startup telegram can be identified on bit 8 of byte 0 and may not be evaluated by the evaluation unit like data telegrams. |

Telegram with CRC of the sensor software:

| Byte 0 | Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 | Byte 7 |
|--------|---------|--------|--------|---------|--------|--------|--------|
| 0xA0 | CRC MSB | CRC | CRC | CRC LSB | FF | 80 | 01 |

Telegram with the software version of the sensor software:

| Byte 0 | Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 | Byte 7 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| 0xA0 | SW MSB | SW | SW | SW LSB | FF | 80 | 08 |

4.3.2 Data telegrams during operation

| Error status | | | Speed | | Position | | |
|---------------|--------------|-------------|-----------|-----------|----------|--------|---------|
| Byte 0 | Byte 1 | Byte 2 | Byte 3 | Byte 4 | Byte 5 | Byte 6 | Byte 7 |
| Error 23 - 16 | Error 15 - 8 | Error 7 - 0 | Speed MSB | Speed LSB | Pos MSB | Pos | Pos LSB |

4.4 Supported commands





In case of an error the bus channels can each be deleted using a reset command. If the error occurs again, carry out the steps in section Failures [► 15].

| Command | | Description |
|---------|-------------------------|-----------------|
| ID | Data | |
| 0x7F0 | 00 0A 01 E2 C9 05 00 17 | Reset Channel A |
| 0x7F0 | 00 0A 01 C2 C9 05 00 17 | Reset Channel B |

| | |
|---------------|---|
| NOTICE | Resetting an error state |
| | The error state for one channel can be deleted using the reset command for the channel in question, or by briefly disconnecting the power supply for both channels. |

4.5 Status LED

A LED signals the status of the device:

| Display | LED | Meaning |
|--------------------|---|--|
| LED off |  | No voltage |
| LED green (5 s) |  | Initialization after switching on |
| LED green flashing |  | BUS communication available on both channels |
| LED red flashing |  | An error occurred, the output data is no longer safe |

4.6 CAN Error Codes

In general, the sensor cannot be repaired. A defective device requires full replacement.

| NOTICE | Safety component traceability |
|---------------|---|
| | <p>Please note that the device is generally a subsystem of a safety system, and therefore the traceability of safety components has to be ensured.</p> <p>Therefore, record which device (serial number) is replaced by which new device (new serial number).</p> |

Several measures have to be carried out if an error occurs that can be traced back to the sensor. For error detection, the error can be read using the connected evaluation unit (for details refer to the corresponding operating instructions).

Causes of error and measures to be carried out:

Worn slide rails (critical error):

In this exceptional case only the slide rails may be replaced (see above). Since forces do not impact the slide rails when installed correctly, worn slide rails indicate an installation error.

- Check that the code band is installed perpendicular and firmly clamped. It has to run through the sensor on the slide rail without pressure.

Dirt on the code band and dirt released from there in the sensor (less common error):

- Check and clean the code band.
- While unplugged, clean the sensor with compressed air.
- Wait one minute before connecting the device again.

**CAUTION****Behavior in case of error**

After each error that sets the device to lock state, it is mandatory to drive through the complete length of the elevator shaft in normal operation without problems. Only then can the elevator be released again.

If errors occur again, the cause has to be investigated. If standard corrective measures are insufficient, then replacement of the complete unit is necessary.

If mechanical parts of the device are bent or battered, then the device must be replaced. In addition, check how a mechanical load on the device was possible given that, in normal operation, no forces are to impact the device (except weak friction from the band).

| Designation | Bit number | Category | Possible cause |
|--|------------|----------------|--|
| Error on another channel | 0 | Warning / info | The other channel has an error. |
| Advance warning for position deviation. | 1 | Warning | Dirt on band and possibly sensor (resets when there is movement). |
| Advance warning for position imprecision. | 2 | Warning | Dirt on band and possibly sensor, release sometimes reduced (still only 2-6 mm) (resets when there is movement). |
| Code band error when switching on the LES02D. | 3 | Error | Dirt on band and possibly sensor (can happen at beginning). |
| Measurement of clock track not possible (small holes). | 4 | Error | Slide rails, band guide, sensor possibly defective. |
| Missing code band. | 5 | Error | No band. |
| Internal error. | 6 | Error | Sensor defective. |
| Inclination error | 7 | Error | Installation, collision |
| Faulty position data. | 8 | Error | Dirt on band and possibly sensor, sensor defective. |
| Internal error. | 9 | Error | Error on another channel (was reset), sensor defective. |
| Internal error. | 10 | Error | Sensor defective. |
| BUS error. | 11 | Error | Incorrect CAN cabling, other invalid CAN participants, sensor defective. |
| Internal error. | 12 | Error | Sensor defective. |
| Acceleration values implausible. | 13 | Error | Installation, collision, sensor possibly defective. |
| Code track measurement (large holes). | 14 | Error | Dirt on band and possibly sensor, sensor defective. |
| Installation error. | 15 | Error | Sensor installed incorrectly. |
| Excessive speed. | 16 | Error | Speed above 10.5 m/s. |
| Internal error. | 17 | Error | Sensor defective. |
| Internal error. | 18 | Error | Sensor defective. |
| Internal error. | 19 | Error | Sensor defective. |
| Internal error. | 20 | Error | Sensor defective. |
| | 21 | | |
| Acceleration too high. | 22 | Error | Free fall detected, sensor possibly defective. |
| Identifying startup telegram. | 23 | Info | Bit that was set during startup, no error but the rest of the data must not be interpreted. |

4.7 Failures

The measurement system does not communicate with the controller.

- a) Check the supply voltage.
- b) Check that the electrical installation is correct, especially the wiring.
- c) Ensure that the connection to the CAN bus is installed properly. If necessary, use a CAN monitor to check data transmission.
- d) Ensure that the evaluation unit is compatible with the sensor.
- e) After the sensor is installed, make sure the code band direction matches the direction specified on the sensor identification plate (direction of large and small holes).
- f) Inspect the slide rails for serious wear.
- g) In case of an error, reset the sensor if necessary.

5 Disposal

Always dispose of unusable or irreparable devices in an environmentally sound manner, according to the country-specific provisions and in compliance with the waste disposal regulations in force. We will be glad to help you dispose of the devices.

See chapter Contact [▶ 19].

NOTICE



Environmental damage in case of incorrect disposal

Electrical waste, electronic components, lubricants and other auxiliary materials are subject to hazardous waste treatment. Problem substances may only be disposed of by licensed specialist companies.

Dispose of disassembled device components as follows:

- Metal components in the scrap metal.
- Electronic components in the electrical waste.
- Plastic parts in a recycling center.
- Sort and dispose of the other components depending on the material type.

6 Annex

6.1 Decimal / Hexadecimal conversion table

| Dec | Hex | Dec | Hex | Dec | Hex | Dec | Hex | Dec | Hex |
|-----|------|-----|------|-----|------|-----|------|-----|------|
| 0 | 0x0 | 51 | 0x33 | 102 | 0x66 | 153 | 0x99 | 204 | 0xCC |
| 1 | 0x1 | 52 | 0x34 | 103 | 0x67 | 154 | 0x9A | 205 | 0xCD |
| 2 | 0x2 | 53 | 0x35 | 104 | 0x68 | 155 | 0x9B | 206 | 0xCE |
| 3 | 0x3 | 54 | 0x36 | 105 | 0x69 | 156 | 0x9C | 207 | 0xCF |
| 4 | 0x4 | 55 | 0x37 | 106 | 0x6A | 157 | 0x9D | 208 | 0xD0 |
| 5 | 0x5 | 56 | 0x38 | 107 | 0x6B | 158 | 0x9E | 209 | 0xD1 |
| 6 | 0x6 | 57 | 0x39 | 108 | 0x6C | 159 | 0x9F | 210 | 0xD2 |
| 7 | 0x7 | 58 | 0x3A | 109 | 0x6D | 160 | 0xA0 | 211 | 0xD3 |
| 8 | 0x8 | 59 | 0x3B | 110 | 0x6E | 161 | 0xA1 | 212 | 0xD4 |
| 9 | 0x9 | 60 | 0x3C | 111 | 0x6F | 162 | 0xA2 | 213 | 0xD5 |
| 10 | 0xA | 61 | 0x3D | 112 | 0x70 | 163 | 0xA3 | 214 | 0xD6 |
| 11 | 0xB | 62 | 0x3E | 113 | 0x71 | 164 | 0xA4 | 215 | 0xD7 |
| 12 | 0xC | 63 | 0x3F | 114 | 0x72 | 165 | 0xA5 | 216 | 0xD8 |
| 13 | 0xD | 64 | 0x40 | 115 | 0x73 | 166 | 0xA6 | 217 | 0xD9 |
| 14 | 0xE | 65 | 0x41 | 116 | 0x74 | 167 | 0xA7 | 218 | 0xDA |
| 15 | 0xF | 66 | 0x42 | 117 | 0x75 | 168 | 0xA8 | 219 | 0xDB |
| 16 | 0x10 | 67 | 0x43 | 118 | 0x76 | 169 | 0xA9 | 220 | 0xDC |
| 17 | 0x11 | 68 | 0x44 | 119 | 0x77 | 170 | 0xAA | 221 | 0xDD |
| 18 | 0x12 | 69 | 0x45 | 120 | 0x78 | 171 | 0xAB | 222 | 0xDE |
| 19 | 0x13 | 70 | 0x46 | 121 | 0x79 | 172 | 0xAC | 223 | 0xDF |
| 20 | 0x14 | 71 | 0x47 | 122 | 0x7A | 173 | 0xAD | 224 | 0xE0 |
| 21 | 0x15 | 72 | 0x48 | 123 | 0x7B | 174 | 0xAE | 225 | 0xE1 |
| 22 | 0x16 | 73 | 0x49 | 124 | 0x7C | 175 | 0xAF | 226 | 0xE2 |
| 23 | 0x17 | 74 | 0x4A | 125 | 0x7D | 176 | 0xB0 | 227 | 0xE3 |
| 24 | 0x18 | 75 | 0x4B | 126 | 0x7E | 177 | 0xB1 | 228 | 0xE4 |
| 25 | 0x19 | 76 | 0x4C | 127 | 0x7F | 178 | 0xB2 | 229 | 0xE5 |
| 26 | 0x1A | 77 | 0x4D | 128 | 0x80 | 179 | 0xB3 | 230 | 0xE6 |
| 27 | 0x1B | 78 | 0x4E | 129 | 0x81 | 180 | 0xB4 | 231 | 0xE7 |
| 28 | 0x1C | 79 | 0x4F | 130 | 0x82 | 181 | 0xB5 | 232 | 0xE8 |
| 29 | 0x1D | 80 | 0x50 | 131 | 0x83 | 182 | 0xB6 | 233 | 0xE9 |
| 30 | 0x1E | 81 | 0x51 | 132 | 0x84 | 183 | 0xB7 | 234 | 0xEA |

| Dec | Hex | Dec | Hex | Dec | Hex | Dec | Hex | Dec | Hex |
|-----|------|-----|------|-----|------|-----|------|-----|------|
| 31 | 0x1F | 82 | 0x52 | 133 | 0x85 | 184 | 0xB8 | 235 | 0xEB |
| 32 | 0x20 | 83 | 0x53 | 134 | 0x86 | 185 | 0xB9 | 236 | 0xEC |
| 33 | 0x21 | 84 | 0x54 | 135 | 0x87 | 186 | 0xBA | 237 | 0xED |
| 34 | 0x22 | 85 | 0x55 | 136 | 0x88 | 187 | 0xBB | 238 | 0xEE |
| 35 | 0x23 | 86 | 0x56 | 137 | 0x89 | 188 | 0xBC | 239 | 0xEF |
| 36 | 0x24 | 87 | 0x57 | 138 | 0x8A | 189 | 0xBD | 240 | 0xF0 |
| 37 | 0x25 | 88 | 0x58 | 139 | 0x8B | 190 | 0xBE | 241 | 0xF1 |
| 38 | 0x26 | 89 | 0x59 | 140 | 0x8C | 191 | 0xBF | 242 | 0xF2 |
| 39 | 0x27 | 90 | 0x5A | 141 | 0x8D | 192 | 0xC0 | 243 | 0xF3 |
| 40 | 0x28 | 91 | 0x5B | 142 | 0x8E | 193 | 0xC1 | 244 | 0xF4 |
| 41 | 0x29 | 92 | 0x5C | 143 | 0x8F | 194 | 0xC2 | 245 | 0xF5 |
| 42 | 0x2A | 93 | 0x5D | 144 | 0x90 | 195 | 0xC3 | 246 | 0xF6 |
| 43 | 0x2B | 94 | 0x5E | 145 | 0x91 | 196 | 0xC4 | 247 | 0xF7 |
| 44 | 0x2C | 95 | 0x5F | 146 | 0x92 | 197 | 0xC5 | 248 | 0xF8 |
| 45 | 0x2D | 96 | 0x60 | 147 | 0x93 | 198 | 0xC6 | 249 | 0xF9 |
| 46 | 0x2E | 97 | 0x61 | 148 | 0x94 | 199 | 0xC7 | 250 | 0xFA |
| 47 | 0x2F | 98 | 0x62 | 149 | 0x95 | 200 | 0xC8 | 251 | 0xFB |
| 48 | 0x30 | 99 | 0x63 | 150 | 0x96 | 201 | 0xC9 | 252 | 0xFC |
| 49 | 0x31 | 100 | 0x64 | 151 | 0x97 | 202 | 0xCA | 253 | 0xFD |
| 50 | 0x32 | 101 | 0x65 | 152 | 0x98 | 203 | 0xCB | 254 | 0xFE |
| | | | | | | | | 255 | 0xFF |

7 Contact

You want to get in touch with us:

Technical advice

For technical advice, analysis or support during installation, Kübler is directly on site with its globally active application team.

Support International (English-speaking)

+49 7720 3903 849

support@kuebler.com

Kübler Germany +49 7720 3903 849

Kübler Australia +61 3 7044 0090

Kübler China +86 10 8471 0818

Kübler France +33 3 89 53 45 45

Kübler India +91 8600 147 280

Kübler Italy +39 0 26 42 33 45

Kübler Austria +43 3322 43723 12

Kübler Poland +48 6 18 49 99 02

Kübler Turkey +90 216 999 9791

Kübler USA +1 855 583 2537

Repair service / RMA-Form

For returns, please pack the product adequately and enclose the completed "Returns Form".

www.kuebler.com/rma

Send your return, specifying the RMA-reference, to the following address.

Kübler Group Fritz Kübler GmbH

Schubertstraße 47
D-78054 Villingen-Schwenningen
Deutschland

Tel. +49 7720 3903 0

Fax +49 7720 21564

info@kuebler.com

www.kuebler.com

Glossary

CAN

Controller Area Network

CAN-ID

CAN Identifier - Assembled messages identifier per device

CRC

Cyclic Redundancy Check

EN 60529

Degrees of protection provided by enclosures (IP Code)

EN 12015

Electromagnetic compatibility - Product family standard for lifts, escalators and moving walks - Emission

EN 12016

Electromagnetic compatibility - Product family standard for lifts, escalators and moving walks - Immunity

EN 61140

Protection against electric shock - Common aspects for installation and equipment

LED

Light Emitting Diode. Semiconductor component that emits light.

LES

Linear Encoder Safe

LSB

engl. Least Significant Bit

MSB

engl: Most Significant Bit

RMA

Return Material Authorization, authorization to return material, e.g. in the case of complaints.

SIL

Safety Integrity Level

UL

Underwriters Laboratories (Inc.). US organization for the certification of electrotechnical products



Kübler Group
Fritz Kübler GmbH
Schubertstr. 47
D-78054 Villingen-Schwenningen
Germany
Phone +49 7720 3903-0
Fax +49 7720 21564
info@kuebler.com
www.kuebler.com